INSTALLATION DIAGRAM

The Greenwald Pay Plus device installs in-between the machine control panel and card reader



GREENWALD PAY PLUS DEVICE LED CODES

COLOR	ACTIVITY	SIGNIFICANCE	
Off	Off	Device not connected to power	
White	Slow Blink	Device not configured	
Blue	Steady	Selected during configuration	
Yellow	Slow Blink	Loading machine configuration	
Green	Steady	Configured & ready	
Blue	Slow Blink	Active with phone app	
Green	Fast Blink	Active, Start not pressed	
Green	Slow Blink	Busy, machine running	
Red	Slow Blink	Machine Error	
Red	Fast Blink	Machine Interface Error	
Blue/Green	Slow Toggle	Firmware Loading	
Red	Steady	Firmware Error	

MACHINE ERROR CODES

ERROR CODE	SIGNIFICANCE	RESOLUTION	
C RE	Card Reader Error. Disconnection detected	Re-connect card reader harness	EN20-115



Greenwald Pay Plus Installation Instructions LG Machines

> Kit #: 4116-001 INS. 2476-1 Rev A



Tools Needed for Installation





Greenwald Industries

212 Middlesex Avenue | Chester, CT 06412 USA 800-221-0982 | www.greenwaldindustries.com



