

Slide Activated Starters

Start Front-Loading Washers from Coin Insertion




Features

Starts coin activated washing machines

Set desired number of coins with simple turn-dial CAM

Use with:
Electrolux
General Electric
Sears
SpeedQueen
Wascomat



Greenwald Industries' 7600 Series Slide Activated Starters provide a simple solution to start a washer from one to seven coin slide insertions. The desired number of coin insertions is easily "dialed in" by positioning a tab in any one of the seven-marked positions on the CAM.

Full 1-year warranty. Made in the USA.

Slide Activated Starters for Front-Loading Washers

Manufacturer	Voltage	Greenwald Model #
Electrolux	110V AC	76-1030-23
General Electric	110V AC	76-1030-23
Sears	110V AC	76-1030-23
SpeedQueen	110V AC	76-1040-01
Wascomat	110V AC	76-1030-11
Wascomat	220V AC	76-1030-12
Wascomat (newer models)	110V AC	76-1030-21
Wascomat (newer models)	220V AC	76-1030-21

Manual Starters for Front-Loading Washers

Description	Greenwald Model #
Manual Set Starter, 110V AC, 15M	15-1000-1
Manual Set Starter, 110V AC, 30M	15-1000-2
Manual Set Starter, 110V AC, 60M	15-1000-2
Manual Set Starter, 220V AC, 60M	38-1000-7

