


7600 Series Start Mechanism Exploded View / Parts List

PARTS LIST FOR SERIES 7682 "QUICK-CHANGE" START MECHANISM

ITEM 27A: MODELS 76-1030-21 (115V-60Hz),
76-1030-22 (230V-60Hz)

ITEM 27B: MODELS 76-1030-11 (115V-60Hz),
76-1030-12 (230V-60Hz)



ITEM	REQ'D	PART NO.	DESCRIPTION
1	2	00-7185	#4-40 SELF-TAPPING SC.
2	1	76-6009-*	TIMER MOTOR ASS'Y
3	1	76-1037	SWITCH & BRACKET SUB-ASSY
4	1	76-5014	DRIVE SLEEVE
5	1	76-2033	SLEEVE
6	1	00-8149	TORSION SPRING
7	3	00-7070	RETAINING RING
8	2	76-5013	DRIVE BUSHING
9	1	00-8003	SPRING
10	1	76-1036	RATCHET ARM & PAWL ASSY
11	1	76-5017	RATCHET WHEEL
12	1	76-2003	WASHER
13	1	59-204	SPRING
14	1	76-5012	CAM
15	1	76-5010	ADJUSTER TAB
16	1	00-7055	SPRING WASHER
17	1	00-7047	WASHER

ITEM	REQ'D	PART NO.	DESCRIPTION
18	1	76-2026	DRIVE SHAFT
19	2	00-7458	#4-40x1 3/16 PAN HD SC.
20	2	00-7097	#4 SPLIT LOCKWASHER
21	1	00-6189	SNAP SWITCH
22	1	00-6190	SNAP SW. & LEVER ARM ASSY
23	1	76-5009	SWITCH INSULATOR
24	1	76-2035	NUT PLATE
25	1	76-6000	WIRE HARNESS ASSY
26	2	02-0810-00	#8-32x5/16 SEMS SCREW
27A	1	76-2059	MOUNTING BRACKET
27B	1	76-2027	MOUNTING BRACKET
28	1	59-0314	CABLE TIE
29	1	58-172-*	GROUND WIRE
30	1	00-7558	WASHER